

	LOMBARDINI		DEUTZ						
	AIR COOLED		AIR COOLED			OIL COOLED			
	GBA12L	GSA12L	GBA6D-17D	GSA22D-30D	GSA42D-65D	GBL22D-30D	GBL42D	GSL22D-30D	GSL42D
<b>GEN SET</b>									
Galvanized skid base frame with integrated drip tray and fork lift channels (only soundproof versions)	-	-	-	-	-	-	-	o	o
Leak proof tray (only for soundproof versions)	-	-	-	-	o	-	-	-	-
Site trailer (only for soundproof versions)	-	-	-	-	o	o	o	o	o
Road trailer-rigid bar (only for soundproof versions)	-	-	-	-	o	o	o	o	o
Sockets kit (only soundproof versions)	-	-	-	-	o	•	•	o	o
Rental kit (battery switch, socket panel according to size, Fuel filter with water separator and drain, earth rod with cable and three way fuel valve for connection to external tank)	-	-	-	-	-	-	-	o	o
Ligthing tower	-	-	-	-	-	o	o	o	o
<b>ENGINE</b>									
Engine electronic governor	-	-	-	o	o	o	o	o	o
Coolant pre-heating system (for automatic start)	-	-	-	o	o	o	o	o	o
Residential silencer (standard on soundproof versions)	-	-	-	o	o	-	-	o	o
<b>FUEL SYSTEM</b>									
Automatic fuel transfer pump	-	-	-	o	o	-	-	o	o
<b>ALTERNATOR (STAMFORD)</b>									
Alternator parallel kit (with mains)	-	-	-	-	-	-	-	-	-
Alternator parallel kit (with other alternator)	-	-	-	-	-	-	-	-	-
PMG alternator variant	-	-	-	-	o	-	-	-	o
<b>OTHER OPTIONS</b>									
Manual Control Panel with analogue instrumentation	-	•	-	o	o	•	•	•	•
Load Transfer Switch Panel (LTS) for ACP versions	-	o	-	o	o	o	o	o	o
Connection kit for communication via Modem / GSM (only for automatic versions)	-	-	-	o	o	-	-	o	o

- : Standard
- o: Optional
- (-): Not available

	PERKINS	DEUTZ				VOLVO			
	WATER COOLED								
	GSW15P-22P	GSW65D-80D	GSW110D 145D	GSW170D	GSW530D 560D	GSW195V 220V	GSW275V	GSW330V 415V 450V	GSW510V 560V 590V
<b>GEN SET</b>									
Galvanized skid base frame with integrated driptray and fork lift channels	☐	☐	☐	☐	-	☐	○	-	-
Leak proof tray	●	●	●	●	●	●	●	●	●
Site trailer	☐	☐	☐	☐	-	☐	○	-	-
Road trailer-rigid bar	☐	☐	☐	☐	-	☐	○	-	-
Sockets kit	☐	☐	☐	☐	-	☐	○	○	○
Rental kit (battery switch, socket panel according to size, Fuel filter with water separator and drain, earth rod with cable and three way fuel valve for connection to external tank)	○	○	○	○	-	○	○	-	-
Ligthing tower	-	-	-	-	-	-	-	-	-
<b>ENGINE</b>									
Engine electronic governor	-	○	○	○	●	●	●	●	●
Coolant pre-heating system (for automatic start)	○	○	○	○	○	○	○	○	○
Residential silencer (standard on soundproof versions)	●	○	○	○	○	○	○	○	○
<b>FUEL SYSTEM</b>									
Automatic fuel transfer pump	○	○	○	○	○	○	○	○	○
<b>ALTERNATOR (STAMFORD)</b>									
Alternator parallel kit (with mains)	-	○	○	○	○	○	○	○	○
Alternator parallel kit (with other alternator)	-	○	○	○	○	○	○	○	○
PMG alternator variant	-	○	○	○	○	○	○	○	○
<b>OTHER OPTIONS</b>									
Manual Control Panel with analogue instrumentation	●	○	○	○	-	○	-	-	-
Load Transfer Switch Panel (LTS) for ACP versions	○	○	○	○	○	○	○	○	○
Connection kit for communication via Modem / GSM (only for automatic versions)	○	○	○	○	○	○	○	○	○

- : Standard
- : Optional
- ☐: Optional (only soundproof versions)
- (-): Not available